<u>Date Purchased:</u>
Date Fitted:
Fitment By:
Km/Mi at Fitment:

Maximum carrying capacity:

Vehicle	On Road Cargo Allowance	Off Road Cargo Allowance	Roof Allowance	Rack Weight (2.5kg per bar)
VW Caddy/ Caddy Maxi MY11 - on (2 bar)	95kg / 209lbs	63kg / 138lbs	100kg / 220lbs	5kg / 11lbs
VW Caddy/ Caddy Maxi MY11 - on (3 bar)	92kg / 202lbs	61kg / 134lbs	100kg / 220lbs	7.5kg / 11lbs
Mitsubishi Triton Dble Cab/ 2dr Club Cab 04/15 on	75kg / 165lbs	50kg / 110lbs	80kg / 176lbs	5kg / 11lbs

Off Road: Any driven path taken that is not on sealed (tarred / bitumen) and maintained

Roof Allowance: Total permissible weight attached to the roof of the car. This is inclusive of the weight of the roof rack system

Cargo Allowance: Total permissible weight allowed on top, and attached to roof racks whilst the vehicle is in motion

Static Allowance: Total permissible weight allowed on top, and attached to roof racks whilst the vehicle is stationary

Load must be evenly distributed over the roof racks. Weight of roof rack accessories is to be included in cargo allowance.

Torque settings

Unless stated otherwise in these instructions, all fasteners should be set to the following torque settings -

M6: 4-5Nm (3-4lbs/ft), M8: 8-10Nm (6-7.5lbs/ft) and M10: 16-18Nm (12-13lbs/ft).

Warning:

- Check the Rhino-Rack website to ensure you have the latest issue of the instructions
- · Check Part No. and / or Kit is correct for use with your vehicle
- Do not attempt to fit the rack system to your vehicle unless you fully understand these fitting instructions. Please direct any questions regarding fitting to the dealer from where the roof racks were purchased.
- Use only non-stretch fastening ropes or straps.
- The handling characteristics of the vehicle changes when you transport a load on the roof. For safety reasons we recommend you
 exercise extreme care when transporting wind-resistant loads. Special consideration must be taken into account when cornering and
 braking.
- Although the system is tested and approved to AS1235-2000 / ISO 11154, off-road conditions can be much more rigorous. Extreme care
 must be taken in off road conditions

Recommendations:

It is essential that all bolt connections be checked after driving a short distance when you first install your roof racks. Bolt connections should be checked again at regular intervals (once a week is enough, depending on road conditions, usage, loads and distances travelled). You should also check the roof racks each time they are re-fitted. Always make sure to fasten your load securely. Please also ensure that all loads are evenly distributed and that the centre of gravity is kept as low as possible and must be entirely contained within the extents of the roof racks.

Note for Dealers and Fitters:

It is your responsibility to ensure these fitting instructions are given to the end user or client.


Rhino-Rack, 22 Hanson PI, Eastern Creek NSW 2766, Australia

 NSW 2766, Australia
 Document No:
 R1328

 (02) 8846 1900
 Issue No:
 03

 rhinorack.com.au
 Issue Date:
 13/08/2019

These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.



Page 2 of 8

RCP47-BK Base Kit 3 3mm then References 11mm drill bit. made previous. Dremel. Ditch fill. 5 (A) (B) Item 8. Mitsubishi Triton Club Cab Ditch fill. 2 - Marker pen.

RCP47-BK Base Kit 3 Ditch fill. - 3mm bit then 11mm drill bit. - Dremel. 5 (A) (B) Item 8. Installing the leg kit Tab inserts to outside of vehicle. В Tighten 3-4 Nm while visually watching the roof panel. Over tightening can damage the roof of the vehicle.

VW Caddy/ Caddy Maxi MY11 on Instructions 3 Crossbars: Front, middle and rear mount points used. Additional RCP47H-BK required. Store in safe place. - 2 Crossbars: Front mounting point and either middle OR rear mounting point

