



Hi-Lift Jack Parts List

1. Top clamp-clevis (C7 or S7)

2. Top clamp-clevis bolt & nut (20-21)

3. Steel standard bar (B42C, B48C, B60C, B36P, B42P, B48P, or B60P)

4. Reversing latch (C4)

5. Handle clip spring (31)

6. Cap screw with washer (22A)

7. Steel handle with cotter pin (15-25)

8. Handle socket (C2 or S2)

9. Pitman pin (30)

10. Pitman (C3 or S3)

11. Hex bolt & nut (16A-17)

12. Large runner (C10)

13. Reversing switch spring (27A)

14. Reversing switch cam bar (C5)

15. Cross pin (26)

16. Climbing pin (29)

17. Climbing pin spring (28)

18. Small runner (C1)

19. Shear bolt & nut (18A-19)

20. Foot piece with cotter pin (C6-24 or S6-24)

