

Tel: +61 3 9761 6622 • Fax: +61 3 9761 6807

www.arb.com.au ABN 31 006 708 756

OMEGS19 GREASABLE SHACKLE KIT

<u>CONTENTS</u>

Part Number	Qty	Description
3199936	2	Side Plate
3199962L	1	Side Plate anti inversion
3199963R	1	Side Plate anti inversion
GSMP14	2	Shackle pin
GSMP15	2	Shackle pin
6151062	8	M14 x 1.5 nut
6151064	8	Spring washers
5728013	4	Grease nipple

INSTALLATION PROCEDURE

ANTI INVERSION POINT RHS SHOWN	 Remove OE shackle plates and pins following manufactures procedures. Pre assemble outer side of shackle. Lubricate bushes before assembly to assist fitment. Fit bushes (supplied separately) to spring eye and vehicle spring hanger. Fit shackle assembly with anti inversion point facing toward front of vehicle. (see below) Tighten nuts to 81Nm. Fit grease nipples and grease assembly using a grease gun.
RHS SHOWN	FRONT OF VEHICLE